

HANDY HINTS SHEET 6

...helping you get started.

How To Make A Perfect Corner

YOU WILL NEED

WAX FILLER



CLOTHS



Here is a great tip in the framing world to get the best results for every frame:

Once you have joined the frame and the glue has dried, take another look at the corners of your frame and inspect the quality.

Any visible gaps should be filled using an Amaco Wax Filler. To do this simply cover the gap with the filler, pushing it into the crevice with a finger or cloth. Be sure to fill all sides of the moulding (apart from the back & rebate depth).

Then, using a cloth, wipe away any excess filler. Make sure to check your hands for any wax that might stain the frame when handling it.

Lastly, hold your frame up to the light and make sure you cannot see any wax residue or smears on the surface.

THESE WAXES CAN BE AVAILABLE IN A NUMBER OF DIFFERENT COLOURS

